



4119 White Bear Parkway, St. Paul, MN 55110 USA
Phone (651) 429-1100, Fax (651) 429-1122
Toll Free (800) 4-CORTEC, E-mail info@cortecvc.com
Internet http://www.cortecvc.com

Determination of Best Rust Preventative on Steel Rods

To: Customer

From: Cortec Corporation Laboratories
4119 White Bear Parkway
St. Paul, MN 55110

cc: Boris Miksic
Anna Vignetti
Jessica Scott

Project #: 12-222-1825.bis

Test conducted by:

Handwritten signature of Caleb Pheneger in black ink.

Caleb Pheneger
Technical Service Engineer

Approved by:

Handwritten signature of Margarita Kharshan in black ink.

Margarita Kharshan
Laboratory Director

Date: October 29, 2012



Background: The customer wants to compare a current rust preventative to 3 different Cortec products on steel rods.

Sample Received:

- Five steel rods that range between 5 and 7.5 inches in length and approximately 1.5 inches in diameter with highly polished finish.
- One container of Wlover rust preventative

Method: ASTM D-1748 Modified (120°F, ~99% relative humidity)

Materials: Metal parts for testing
VpCI-414 for cleaning parts
BioCorr
VpCI-325
Ecoline 3690
Wlover rust preventative
Clear VCI-free polyethylene bags

Procedure: The following procedure was used:

- 1) Clean all 5 steel rods using VpCI-414 in dip tank and let dry.
- 2) Apply each of the rust preventatives by dipping:
 - a. Wlover RP
 - b. BioCorr
 - c. VpCI-325
 - d. Ecoline 3690
 - e. No rust preventative (Control)
- 3) Stand the steel rod on the end to let excess rust preventative run off the part overnight
- 4) Place each steel rod in a clear VCI-free polyethylene bag with label to identify the rust preventative used.
- 5) Put all 5 parts in the humidity chamber and monitor the parts for corrosion

Results: Table 1: Results of ASTM D-1748 Modified

| Rust Preventative | Time Until Failure (Hours) |
|-------------------|----------------------------|
| None (Control) | < 24 |
| Wlover | 72 |
| Ecoline 3690 | 240 |
| BioCorr | 144 |
| VpCI-325 | DNF* |

* Did Not Fail (DNF) during 240 hours of testing

Interpretations:

After 240 hours of humidity testing VpCI-325 performed the best according to both failure time and visual inspection. Ecoline 3690 provided the next best protection, with only 3 minute corrosion spots after 240 hours of testing. Both BioCorr and Wallover RP slightly outperformed the part with no rust preventative. From these results it is apparent that a water based rust preventative is not suitable for long term corrosion inhibition on these highly polished steel rods.

Photos: The following photos were taken after 240 hours in the humidity chamber:



Figure 1: No Rust Preventative (Control)



Figure 2: BioCorr



Figure 3: Wallover RP



Figure 4: Ecoline 3690



Figure 5: VpCI-325